


REAR VIEW AND CONNECTORS



<CN702 12P CONNECTOR>



1. Audio Right (+)
2. Audio Left (+)
3. Signal Ground
4. Mute
5. Power Supply, +B
6. Audio Right (-)

7. Audio Left (-)
8. Ground
9. Communicat
10. Communicat
- 11.
12. Power Suppl

Aftermarket Stereo

SWITCHED IGNITION POWER



CONSTANT BATTERY POWER



CHASSIS NEGATIVE GROUND



ILLUMINATION



AMPLIFIER TURN ON



POWER ANTENNA



DIMMER



LEFT FRONT POSITIVE



LEFT FRONT NEGATIVE



LEFT REAR POSITIVE



LEFT REAR NEGATIVE




RIGHT REAR POSITIVE



RIGHT REAR NEGATIVE









FRONT DISPLAY
INTERFACE
MODULE (FDIM)
151-7

8

AUDIO
CONTROL
MODULE (ACM)
151-7



VME14 GY-YE
RIME24 BU-WH
RIME46 WH-GN
VME46 BU-GN
RIME45 YE-GN
VME45 BU
GD114 BK-BU




Power Antenna

Remote Turn On

Battery

Accessory

Illumination



Components

Car Radio Battery Constant 12V+ Wire

Car Radio Accessory Switched 12V+ Wire

Car Radio Ground Wire

Car Radio Illumination Wire

Car Radio Antenna Trigger Wire

Left Front Speaker Positive Wire (+)

Left Front Speaker Negative Wire (-)

Right Front Speaker Positive Wire (+)

Right Front Speaker Negative Wire (-)

Left Rear Speaker Positive Wire (+)

Left Rear Speaker Negative Wire (-)

Right Rear Speaker Positive Wire (+)

Right Rear Speaker Negative Wire (-)